

POR FAVOR CONSERVE ESTE INSTRUCTIVO, LEALO ANTES DE ENSAMBLAR ESTE JUGUETE
READ AND SAVE THESE INSTRUCTIVE



PATIN SPORTY

Modelo / Model

5301

Edad Recomendable :
Age Group :

3 años
years old ~ **6** años
years old

Requiere Ensamblar
por un Adulto
Adult Assembly Required



PRECAUCIONES:

De hacer caso omiso de estas precauciones y de las instrucciones de ensamble pudieran resultar graves lesiones.

- Nunca deje al niño sin supervisión.
- Deje de usar el juguete si llegara a romperse o dañarse.
- Use solo en superficies planas y libres de objetos, que pudieran causar volcadura del juguete.
- Para evitar daños de quemaduras mantenga al niño alejado de radiadores, calentadores, estufas, etc.
- No lo use alrededor de albercas.
- No lo use en calles inclinadas.
- Nunca cargue el juguete con el niño arriba.
- Bloquee escaleras y escalones antes de usarlo.
- Al utilizar el juguete use equipo de protección adecuado.

WARNING:

Failure to follow these warnings and the assembly instructions could result in injury.

- Never leave child unattended. Always keep child in view while in toy.
- Discontinued using the product if it become damage or broken.
- Use only on surfaces that are flat and free of objects that could cause the toy to tip over.
- Avoid burn injuries, keep child away from ranges, radiators, space, heaters, fireplaces, etc.
- Do not use around swimming pools.
- Do not use in sloped streets.
- Never carry it with child on it.
- Block stairs/steps securely before using toy.
- By using the toy use appropriate protective equipment.


Importado por:
MERRY TECH INTERNACIONAL, S. A. DE C.V. Calle Cochimiles,
No. 18480, INT. 821-D, Col. Guaycura Tijuana B.C.N. México
C.P. 22216

Tel: 664 625 1552

Fax: 664 627 0540

K25#530121ES

COMPONENTES / COMPONENTS



BOLSA DE ACCESORIOS / ACCESSORIES BAG

ACCESORIOS INCLUIDOS EN TUBO B /
ACCESORIES INCLUDED IN TUBE B

ENSAMBLE COMO SE MUESTRA EN LAS FOTOS / ASSEMBLY AS SHOWN IN THE PICTURES

