





Ensamble como se muestra en las figuras  
Assembly as shown in the figures

# LISTA DE PARTES / PARTS LIST



Modelo  
Model:

5406

CANDY  
STAR

Edad recomendable  
Age group

3 Años en adelante  
Years old & up

Requiere ensamblar por un adulto  
Adult assembly required

Fabricante:  
MERRY TECH INTERNACIONAL, S.A. DE C.V. Calle Cochimiles,  
No. 18480, INT. 821-D, Col. Guaycura Tijuana B.C.N. México  
C.P. 22216

Tel: 664 625 1552

Fax: 664 627 0540



## PRECAUCIONES:

Hacer caso omiso de estas precauciones y de las instrucciones de ensamble, pudieran resultar graves lesiones.

- Nunca deje a la niña sin supervisión.
- Deje de usar el juguete si llegara a romperse o dañarse.
- Para evitar daños de quemaduras mantenga a la niña alejada de radiadores, calentadores, estufas, etc.
- No recomendable para niñas menores de 3 años
- Contiene pequeños elementos susceptibles de ser ingeridos.
- El embalaje no es un juguete. Conservarlo lejos del alcance de los niños.
- No deje que la niña se siente sobre el juguete.



## WARNING:

Failure to follow these warnings and the assembly instructions could result in injury.

- Never leave child unattended.
- Discontinue using the product if it becomes damaged or broken.
- Avoid burn injuries, keep child away from ranges, radiators, space, heaters, fireplaces, etc.
- Not for kids under 3 years old.
- Contains little pieces that could be swallowed.
- The box is not a toy. Keep out of the reach of children.
- Do not let the child sit on the toy.



Tocador infantil

