POR FAVOR CONSERVE ESTE INSTRUCTIVO, LEALO ANTES DE ENSAMBLAR Y USAR ESTE PRODUCTO
READ AND SAVE THIS INSTRUCTIVE

MyToy®

Modelo / Model
5567

TRICICLO DE PEDALES

Edad recomendable / Age group:
2 años years old - **5** años years old

Figura musical
Musical figure
requiere 2 pilas "AA" (no incluidas)
2 "AA" batteries required(not included)

HELLO NINNY TRIKE

Importado por:
MERRY TECH INTERNACIONAL, S. A. DE C.V. Calle Cochimies, No. 18480, INT. 821-D, Col. Guaycura Tijuana B.C.N. México C.P. 22216
Tel: 664 625 1552 Fax: 664 627 0540

Requiere ensamblar por un adulto
Adult assembly required

⚠ PRECAUCIONES:

De hacer caso omiso de estas precauciones y de las instrucciones de ensamble pudieran resultar graves lesiones.

- Nunca deje al niño sin supervisión. Siempre mantengalo a la vista mientras este en el juguete.
- Deje de usar el juguete si llegara a romperse o dañarse.
- Usese solo en superficies planas y libres de objetos, que pudieran causar volcadura del juguete.
- Para evitar daños de quemaduras mantenga al niño alejado de radiadores, calentadores, estufas, etc.
- No lo use alrededor de albercas.
- No lo use en calles inclinadas.
- Nunca cargue el juguete con el niño arriba.
- Bloquee escaleras y escalones antes de usarlo.
- Asegurese que el producto no sea usado hasta que haya sido ensamblado y revisado por un adulto.

⚠ WARNING:

Failure to follow these warnings and the assembly instructions could result in injury.

- Never leave child unattended. Always keep child in view while in toy.
- Discontinued using the product if it become damage or broken.
- Use only on surfaces that are flat and free of objects that could cause the toy to tip over.
- Avoid burn injuries, keep child away from ranges, radiators, space, heaters, fireplaces, etc.
- Do not use around swimming pools.
- Do not use in sloped streets.
- Never carry it with child on it.
- Block stairs/steps securely before using toy.
- Ensure that the toy vehicle is not used until it has been properly assembled and cheked by an adult person.

Herramienta Necesaria
NO INCLUIDA
tools needed not included



A Ensamble del manubrio / Handlebar assembly



B Ensamble del chasis al respaldo
Mainbody-back assembly



C Ensamble del asiento / Seat assembly



D Ensamble de cubresol/
Canopy assembly

E Ensamble de canasta / Basket assembly



F Ensamble de llanta trasera / Rear wheel assembly

G Ensamble de guardafangos / Fender assembly



H Ensamble de descansapies / Footrest assembly



K Ensamble de tubo trasero / Rear tube assembly



L Ensamble de cinto (plástico)
Plastic belt assembly



K25#556724ES

INSTRUCCIONES DE ENSAMBLE / ASSEMBLY INSTRUCTIONS
ENSAMBLE COMO SE MUESTRA EN LAS FIGURAS / ASSEMBLY AS SHOWN IN FIGURES

A
Ensamble del manubrio con el chasis / Handlebar assembly with mainframe



B
Ensamble del chasis al respaldo / Mainbody-back assembly



C
Ensamble del asiento / Seat assembly



D
Ensamble de cubresol / Canopy assembly



E
Ensamble de canasta / Basket assembly



F
Ensamble de llanta trasera / Rear wheel assembly

Ensamble en ambas llantas / Assembly in both side



G
Ensamble de guardafangos y llanta delantera / Fender and front wheel assembly



H
Ensamble de descansapies / Footrest assembly

Parte trasera del descansapies. Back part of footrest

Parte delantera del descansapies. Front part of footrest

Parte delantera Front part



Parte trasera Back part

K
Ensamble de tubo trasero / Rear tube assembly



L
Ensamble deL cinto (plástico) Belt (plastic) assembly